



Parents' Guide

PAW Patrol: The Movie: Learning Phone





© & TM Spin Master Ltd. 91-003962-000 (IS)

INTRODUCTION

Thank you for purchasing the **PAW Patrol: The Movie: Learning Phone**. Chat with Chase, Marshall and Skye on an interactive play phone! **The PAW Patrol: The Movie: Learning Phone** includes six exciting activities and features that introduce counting, math, matching and more. You can also receive fun voice messages from Chase, Marshall and Skye, and use voice-activated play to make pretend phone calls!



INCLUDED IN THIS PACKAGE

• PAW Patrol: The Movie: Learning Phone

Parents' guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please keep the parents' guide as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

Unlock the Packaging Lock



- Turn the packaging lock counterclockwise several times.
- ⁽²⁾ Pull out the packaging lock and discard.

INSTRUCTIONS

Battery Removal and Installation

- 1. Make sure the unit is turned Off.
- Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.



- 3. Remove old batteries by pulling up on one end of each battery.
- Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
- 5. Replace the battery cover and tighten the screw to secure.

A WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte. Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- · Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Australia/New Zealand:

If you think batteries might have been swallowed or placed inside any part of the body, immediately call the 24-hour Poisons Information Centre on 13 11 26 (in Australia) or 24-hour National Poisons Centre on 0800 764 766 (in New Zealand) for fast, expert advice and go straight to the nearest hospital emergency room.

PRODUCT FEATURES

1. On/Off Button 🔘

To turn the unit **On**, press the **On/Off Button**. Press the **On/Off Button** again to turn the unit **Off**.

2. Character Buttons



Press the **Chase, Marshall** or **Skye Button** to get a voice message. Press the **Rubble** or **Liberty Button** to see fun animations.

3. Learning Game Buttons



Press any of the four Learning Game Buttons to play.

4. Settings Buttons

Press the Settings Button to adjust the ringtone, background music and screen brightness.

5. Number Buttons



Press a Number Button to learn about numbers or to answer number-related questions.

6. Let's Chat Button



Press a Let's Chat Button to enter the Let's Chat activity. This activity uses the voice activation feature. The LED will light up when this feature is activated.

7. Enter Button ENTER

Press the Enter Button to confirm your choice.

8. Left and Right Buttons < >

Press the Left or Right Button to make a selection in activities or menus.

9. Phone Call Buttons 🤳

Press the **Phone Call Button** to make a pretend phone call. You will hear the phone ringing and will then be able to leave a message on the answering machine.

10. Cancel Call Button

Press the Cancel Call Button at any time to exit the current activity.

The **Microphone** is used for the voice activation feature. Be sure to keep the **Microphone** four to five inches from your mouth for best results.

12. Automatic Shut-Off

To preserve battery life, the **PAW Patrol: The Movie: Learning Phone** will automatically turn **Off** after several minutes of inactivity. The unit can be turned **On** again by pressing the **On/ Off Button**. The unit will also automatically turn **Off** when the batteries are very low. A warning will be displayed on screen as a reminder to change the batteries.

ACTIVITIES

1. Connect With Characters

Press the **Chase**, **Marshall** or **Skye Button** to hear a voice message from that character. Press the **Liberty** or **Rubble Button** to see a fun animation of that character.

2. Count in the City

Marshall sees lots of vehicles driving down the streets of Adventure City. Watch carefully and count how many cars pass by. Press a **Number Button** to answer or press the **Left** or **Right Button < >** to choose, then press the **Enter Button** me to confirm.

3. Falling Fireworks

Humdinger's fireworks display goes haywire, and now the people of Adventure City are in danger! Help the pups escape the fireworks and save the crowd by pressing the same **Number Button** that appears on the screen.







4. Finding Chase

Chase is captured by Mayor Humdinger's goons. Remember Chase's pose or shadow, then choose the matching pose or shadow to find and rescue him. Press the Left or Right Button < > to choose, then press the Enter Button (The to confirm.

5. Cloud Catcher Quiz

The Cloud Catcher overloads and releases a bunch of bad weather at once. Stop the Cloud Catcher by solving the equation. Press a **Number Button** to answer and blow into the Microphone to clear the clouds away.

6. Let's Chat

Press the Let's Chat Button and your phone speed dials Chase, Marshall or Skye. Once a pup answers, they will then ask you to tell them about yourself. Speak into the **Microphone** to answer.

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat sources.
- 3. Remove the batteries if the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on a hard surface and do not expose the unit to moisture or water.







TROUBLESHOOTING

If for some reason the program/activity stops working, please follow these steps:

- 1. Turn the unit Off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit back **On**. The unit should now be ready to use again.
- 5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Trade Name:	VTech®
Model:	5393
Product Name:	PAW Patrol: The Movie: Learning Phone
Responsible Party:	VTech Electronics North America, L.L.C.
Address:	1156 W. Shure Drive, Suite 200,
	Arlington Heights, IL 60004
Website:	vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION. CAN ICES-003(B)/NMB-003(B)

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com vtechkids.ca

Read our complete warranty policy online at vtechkids.com/warranty vtechkids.ca/warranty



TM & © 2021 VTech Holdings Limited. All rights reserved. **Printed in China.** 91-003962-000 (9)