

vtech[®]


Instruction Manual

Chompers the Number Dino™



INTRODUCTION

Thank you for purchasing **Chompers the Number Dino™**.
This hungry dino uses silly jokes to teach numbers, counting, colors
and names of foods.



INCLUDED IN THE PACKAGE

- **Chompers the Number Dino™**
- 9 Food Pieces
- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.


ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE


Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

Unlock the Packaging Locks



- ① Rotate the packaging locks 90 degrees counterclockwise.
- ② Pull out the packaging locks and discard.

Remove the Product Attachments



- ① Carefully cut the two ties on the storage door with a pair of scissors and discard.




- ② Open the storage door. Take out the paper inside the dino and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the left side of the dino's body, use a screwdriver to loosen the screw, and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.





WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.

Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.




Activate Normal Play Mode

Before playing with the unit, activate Normal play mode by feeding the dino two **Food Pieces** within 20 seconds.




You will hear three beeps to indicate that the unit is in Normal play mode.

PRODUCT FEATURES

1. **Off/Low/High Volume Selector** 


To turn the unit **On** or adjust the volume, slide the **Off/Low/High Volume Selector** to Low  or High . To turn the unit **Off**, slide the selector to **Off** .

2. **Mode Selector** 

Slide the **Mode Selector** to choose from three activities: Music , Learning  or Quiz  mode.

3. **9 Food Pieces**

Each **Food Piece** features a color, a number and a food. Feed the dino to learn fun facts, listen to sing-along songs or answer questions.



4. 3 Light-Up Buttons

Press the **Light-Up Buttons** to learn about colors and feelings, hear sing-along songs or answer questions.



5. Dino Spinner

Turn the **Dino Spinner** to spin **Food Pieces** inside the dino, play sing-along songs and hear fun facts.



6. Pull Cord

Pull the dino along to hear fun melodies and dino sounds.



7. Storage Door

Keep the storage door closed when feeding the dino the **Food Pieces**. Open the storage door to remove the **Food Pieces**. When playtime is done, store the **Food Pieces** in the compartment.



8. Automatic Shut-Off

To preserve battery life, the **Chompers the Number Dino™** will automatically shut off after several seconds without input. The unit can be turned on again by sliding the **Mode Selector** or the **Off/Low/High Volume Selector** to any position.


TO BEGIN PLAY

Slide the **Off/Low/High Volume Selector** to Low or High volume to turn the unit on, then slide the **Mode Selector** to choose an activity.

ACTIVITIES

1. Music Mode



Slide the **Mode Selector** to  to enter Music mode. Feed the dino, press the **Light-Up Buttons** or turn the **Dino Spinner** to listen to sing-along songs. Pull the dino along to hear melodies and fun sounds.


2. Learning Mode



Slide the **Mode Selector** to  to enter Learning mode. Feed the dino, press the **Light-Up Buttons** or turn the **Dino Spinner** to learn about colors, numbers, food and feelings.

3. Quiz Mode



Slide the **Mode Selector** to  to enter Quiz mode. The dino will ask questions about food, colors, numbers and feelings. Insert a **Food Piece** or press a **Light-Up Button** to answer. Turn the **Dino Spinner** to repeat the question.

SONG LYRICS

Song 1

One crunchy yummy, sweet apple,
Nothing else tastes so fine.

Song 2

Two sweet yellow ears of corn,
they will take some time to grow.
Do you or I or anyone know,
how much I love corn!

Song 3

Three brown potatoes,
make yummy, yummy french fries!

Song 4

Orange carrots are a treat.
Four crunchy carrots help me see!

Song 5

Five mushrooms grow,
in the ground, in the ground.
White mushrooms grow in the ground.

Song 6

One raspberry under a tree,
two for you and three for me.
Four raspberries in my hand,
five on the bush, six turned to jam.

Song 7

Purple grapes
One, two, three, four, five, six, seven,
Purple grapes.
Juicy and delicious,
Purple grapes.

Song 8

Blueberries grow in clusters.
Blueberries, I'll take eight.
Blue in color, sweet in taste.
Blueberries taste great!

Song 9

Little green peas, in the pea pod
taste so fine, taste so fine.
I guess I'll have to count them.
Look, there's nine, look there's nine.

Song 10

Healthy hearty veggies grow in warm sunshine.
So many yummy treats, they all taste so fine.
Lots of healthy food makes me big and strong.
I have so much energy I can roar all day long.

Song 11

I'm a hungry dinosaur,
I like to stomp; I like to roar.
If you can find my favorite treats,
I'll count and sing to you.

Song 12

I would like a nap,
I'm so sleepy now.
Perhaps I need a snack,
I feel much better now.

Song 13

Across the field I run and play.
Happy Dino, sunny day.
Climb on my back, we'll run away.
We'll be friends forever.

Song 14

Sleepy Dino, Happy Dino,
Hungry Dino, Playful Dino,
Green Dino, Veggie Dino.
Won't you play with me?

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or visit our website at **vtechkids.com** and fill out our **Contact Us** form located under the **Customer Support** link.

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5320
Product Name: Chompers the Number Dino™
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAN ICES-003(B)/NMB-003(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

