

User's Manual

Pop & Count Vacuum™



© 2011 VTech Printed in China 91-002591-00x (#)

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the Infant Learning® series of toys.

These unique interactive learning toys directly respond to what children ao naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech®'s Infant Learning®** toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**[®], we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**[®] with the important job of helping your child learn and grow!

sincerely,

Your friends at **VTech**®

To learn more about the **Infant Learning**® series and other **VTech**® toys, visit www.vtechkids.com

Introduction

INTRODUCTION

Thank you for purchasing the VTech[®] Pop & Count Vacuum[™] learning toy!

Your baby can clean up and count their way to learning fun with the **Pop & Count Vacuum**[™] by **VTech**[®]! This little vacuum easily glides across the floor to pick up its colored blocks that have been left about. As each block is picked up, the vacuum responds with fun sounds as the blocks bounce around inside. Three buttons on the toy reinforce counting and number skills as your child plays.



INCLUDED IN THIS PACKAGE

- One VTech[®] Pop & Count Vacuum[™]
- One handle
- One user's manual
- WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.
- NOTE: Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

- 1. Make sure the unit is turned OFF.
- Locate the battery cover on the back of the unit. Use a coin or a screwdriver to loosen the screw.
- Install 2 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)



4. Replace the battery cover and tighten the screw to secure.

BATTERY NOTICE

- The use of new alkaline batteries is recommended for maximum performance.
- · Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).

- · Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbonzinc) or rechargeable (nickel-cadmium).
- Only batteries of the same or equivalent type as recommended are to be used.
- · Batteries are to be inserted with the correct polarity.
- · Exhausted batteries are to be removed from the toy.
- · The supply terminals are not to be short-circuited.
- The toy is not to be connected to more than the recommended number of power supplies.
- · Do not dispose of batteries in fire.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

ASSEMBLY INSTRUCTIONS

With the VTech® Pop & Count VacuumTM, safety comes first. To ensure your child's safety, please only allow an adult to assemble this product.

Attach the **Pop & Count Vacuum**[™]'s handle to the body by inserting the handle into the corresponding slot on the body. You will hear it click into place. Please ensure the handle is attached securely to the body. Once the handle has been attached, it cannot be removed again.



duct Features

PRODUCT FEATURES

1. OFF/VOLUME CONTROL SWITCH

To turn the unit ON, slide the OFF/VOLUME CONTROL SWITCH to the Low (\triangleleft) or High (\triangleleft)) Volume position. To turn the unit OFF, slide the OFF/VOLUME CONTROL SWITCH to the OFF (\bullet) position.

2. MODE SELECTOR

After turning on the unit, turn the MODE SELECTOR to the Learning ($\langle _{\omega} \rangle$) or Music (\Im) Mode position.



3. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech[®] Pop & Count Vacuum[™]** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button or rolling the wheels.

ACTIVITIES

 Turn on the unit in Learn Mode or Music Mode. You will hear a variety of fun sounds, a sung song and playful phrase. The light will flash with the sound.



Activities

- In Learning Mode, press the Number Buttons to learn numbers and to hear a question about picking up blocks. In Music Mode, press the Number Buttons to hear melodies. The light will flash with the sound.
- Press the Puppy Button to hear fun sounds and songs in Learning Mode, and to hear more melodies in Music Mode. The light will flash with the sound.

- 4. Vacuum up the blocks by rolling the Pop & Count Vacuum[™] over them. As each block is picked up, the vacuum responds with fun sounds as the blocks bounce around inside. The light will flash with the sounds.
- After vacuuming the blocks, open the Blocks Container Cover to remove the blocks, to hear funny sounds in Learning Mode and to hear funny sounds and short tunes in Music Mode.









MELODY LIST

- 1. Polly Wolly Doodle
- 2. Hot Cross Buns
- 3. Three Blind Mice
- 4. Pease Porridge Hot
- 5. Hickory Dickory Dock
- 6. Sing a Song of Sixpence

SONG LYRICS

SONG 1 The blocks are here and there, Clean up! Clean up! One two three, Clean along with me!

SONG 2

A B C D E F G, Won't you clean the house with me? Vacuum here, vacuum there, Vacuum, vacuum everywhere. A B C D E F G, Thank you, now the house is clean!

SONG 3

Roll the vacuum, Walk to the beat! Hear the music, Feel happy!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- 2. Keep the unit out of direct sunlight and away from any direct heat source.
- 3. Remove the batteries when the unit will not be in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit OFF.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit ON. The unit should now be ready to play again.
- 5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech®** at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna
- · Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- · Consult the dealer or an experienced radio/TV technician for help

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

