

vtech[®]


Instruction Manual

Smellephant[™]



INTRODUCTION

Join the **Smellephant™** and learn about the senses of smell, sight, sound, taste and touch. Hear the elephant describe a red fruit that tastes sweet and has bumpy seeds—a strawberry!



5 Fruit Play Pieces



INCLUDED IN THE PACKAGE

- Smellephant™
- 5 Fruit Play Pieces
- Quick Start Guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.


NOTE: Please save this Instruction Manual as it contains important information.

ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE : Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

Unlock the Packaging Locks




① Rotate the packaging locks 90 degrees counterclockwise.

② Pull out the packaging locks and discard.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 4 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.

- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

IMPORTANT : INFORMATIONS CONCERNANT LES PILES

Les piles fournies avec le produit permettent de tester le jouet en magasin mais ne sont pas des piles longue durée.

- Mettre en place les piles ou les accumulateurs en respectant les polarités + et –.
- Ne pas mélanger des piles ou des accumulateurs neufs avec des usagés.
- Ne pas mélanger différents types de piles : alcalines, zinc-carbone et rechargeables.
- Seules des piles du type recommandé doivent être utilisées.
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le –).
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée.
- Enlever les piles ou les accumulateurs usagés du jouet.
- Ne les jeter ni au feu ni dans la nature.

PILES RECHARGEABLES

- Enlever, lorsque c'est possible, les accumulateurs du jouet pour les recharger.
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte.
- Ne pas tenter de recharger des piles non rechargeables.

Activate Normal Play Mode

This product is in Try-Me mode in the packaging. After opening the package, cut and remove the string that attaches the **Grape** fruit piece to the elephant's trunk. Remove the fruit piece from the trunk. Slide the **On/Off/Mode Selector** to any mode, and insert the **Lemon** or **Apple** fruit piece onto the elephant's trunk. You will hear three beeps to confirm that you have exited Try-Me mode.

PRODUCT FEATURES

1. Super Trunk

Place fruit on the trunk to learn about colors, numbers and fruit facts. The elephant's trunk will wave with the sounds.




2. Peek-a-Boo Ears

The elephant flips its ears over its eyes to play peek-a-boo and waves its ears to the sounds.



3. On/Off/Mode Selector

Explore the five senses with Free Play, Quiz and Music modes.



4. Light-Up Hand Button

Press the **Light-Up Hand Button** to see it light up and play songs, sounds and elephant fun facts. Press to get hints in Quiz mode.



5. Foot Button

Press the **Foot Button** to play a song or listen to animal sounds and guess which animal you hear.



6. Automatic Shut-Off

To preserve battery life, the **Smellephant™** will automatically shut off after approximately one minute without input. The unit can be turned on again by sliding the **On/Off/Mode Selector**. The unit will also automatically shut off when the batteries are very low.

ACTIVITIES

1. Free Play Mode

Move the **On/Off/Mode Selector** to Free Play mode to play peek-a-boo with the elephant. Place a **Fruit Play Piece** on the trunk to learn about colors, numbers and fruit facts.



2. Quiz Mode

Move the **On/Off/Mode Selector** to Quiz mode to hear questions about the fruits and colors. Place the correct **Fruit Play Piece** on the trunk to answer the questions.



3. Music Mode

Move the **On/Off/Mode Selector** to Music mode to hear songs. Place a **Fruit Play Piece** on the elephant's trunk to hear songs about the strawberry, lemon, apple, orange and grapes. Remove the fruit and press the **Light-Up Hand** or **Foot Button** to hear songs about the **Smellephant™**.



SONG LYRICS

Song 1

I'm an elephant, I use my eyes to see,
And trunk to touch and to smell,
My ears to hear and mouth to taste,
Come and explore with me!

Song 2

Ooh-wee, it's a strawberry!
A fun, fresh, summery strawberry!
Red and delicious,
Ooh-wee, it's a strawberry!
A fun, fresh, summery strawberry!

Song 3

I'm an elephant, I see a strawberry.
It's the color reddy, reddy, red.
I feel little bumps on it, and it tastes sweet.
Come and explore with me!

Song 4

Lemons are zesty, cha cha cha!
Lemons are sour, cha cha cha!
Lemons make lemondade, cha cha cha!
Lemons are bright, cha cha cha!
Lemony lemons, cha cha cha!

Song 5

I'm an elephant, I see lemons.
They're the color yellow, yellow, yellow.
They feel kind of bumpy and taste so sour,
Come and explore with me!

Song 6

I like to crunch on green apples,
Eat them with my trunk.
I like to crunch on green apples,
Cut them into little chunks.
I like green apples, served in a pie.
I share green apples with friends who stop by.

Song 7

I'm an elephant, I see apples.
They're the color greeny, greeny, green.
They smell sweet and sour and taste sweet and sour.
Come and explore with me!

Song 8

Did you know oranges have vitamin C?
Vitamin C helps keep you strong and healthy.
Orange you glad to sing with me?
Da-da-da-da-da-da!

Song 9

I'm an elephant, I see oranges.
They're the color orange, orange, orange.
They smell fresh and juicy and taste sweet and sour.
Come and explore with me!

Song 10

Oh, grapes, how are they shaped?
Grapes can be round like a ball,
Or oval like a small egg.
These grapes come in a bunch,
Perfect to munch, munch, munch!

Song 11

I'm an elephant, I see grapes.
They're the color purple, purple, purple.
They feel smooth and taste so sweet.
Come and explore with me!

Song 12

Elephants love to eat, love to eat, love to eat,

Elephants love to eat, more than half the day.

We use our trunks to smell the fruit, smell the fruit, smell the fruit,

We use our trunks to smell the fruit.

Hungry elephants!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or by going to our website **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5527
Product Name: Smellephant™
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CAN ICES-003 (B)/NMB-003(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

