

User's Manual

Care & Learn Teddy™



© 2011 VTech Printed in China 91-002581-000 (இ)

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, VTech® created the Infant Learning® series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTecho's Infant Learning toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech®** with the important job of helping your child learn and grow!


sincerely,

Your friends at VTech®

INTRODUCTION

Thank you for purchasing the VTech® Care & Learn Teddy™ learning toy!

The VTech® Care & Learn Teddy™ is a playful interactive plush toy for toddlers. Teddy is a great patient and is ready for you to help him feel better. Toddlers can use the stethoscope and touch the hot spot on Teddy's heart to hear playful sounds and phrases. The ear thermometer will check to make sure that Teddy isn't running a fever while the bandage can be used on his arms or legs to help heal any boo-boos. Press his hands, ear, and foot to identify body parts and to hear playful phrases related to each body part.



INCLUDED IN THIS PACKAGE

- One VTech® Care & Learn Teddy™
- One interactive stethoscope
- One thermometer
- One bandage
- One instruction manual

WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and

should be discarded for your child's safety.

Attention: Pour la sécurité de votre enfant, débarrassez-vous

> de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes.

Ils ne font pas partie du jouet.

NOTE: Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

- Make sure the unit is turned OFF.
- 2. Locate the battery cover inside the back of the unit. Use a screwdriver to loosen the screw.
- 3. Install 2 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
- 4. Replace the battery cover and tighten the screw to secure.



BATTERY NOTICE

- The use of new alkaline batteries is recommended for maximum performance.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbonzinc) or rechargeable (nickel-cadmium).
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- · Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- The toy is not to be connected to more than the recommended number of power supplies.
- · Do not dispose of batteries in fire.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

PRODUCT FEATURES

1. ON/OFF SWITCH

To turn the unit **ON**, locate the **ON/OFF SWITCH** inside the back of the unit on the battery compartment. Slide the **ON/OFF SWITCH** to the **ON (:•):** position. To turn the unit **OFF**, slide the **ON/OFF SWITCH** to the **OFF** (•) position.



2. MODE SELECTOR BUTTON

To select a mode of play, press the MODE SELECTOR BUTTON on Teddy's left ear to select PLAY MODE ((a)) or MUSIC MODE(3). The unit will always default to the PLAY MODE when first turned on.



3. AUTOMATIC SHUT-OFF

To preserve battery life, the VTech® Care & Learn Teddy™ learning toy will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button.

ACTIVITIES

 Slide the on/off switch to turn the unit on, then select a mode of play. You will hear a fun phrase and sing-along song in the play mode. In the music mode, you will hear a fun phrase and a short tune. The light-up nose will flash with the sound.



 Press Teddy's right ear, hands, right foot and tummy to learn about body parts and hear fun sounds in the play mode. In the music mode, you will hear fun sounds and melodies. The light-up nose will flash with the sound.



- Press the music button to play a variety of melodies in both the play mode and the music mode. The lightup nose will flash with the sound.
- 4. The thermometer will check to make sure that Teddy isn't running a fever. Press the button on the back of the thermometer to scroll through the temperatures. Please note, there are no electronics in the thermometer, it is for role-play only.
- 5. Hold the end of the interactive stethoscope up to the heart on Teddy's shirt to activate the sensor. You will hear playful and endearing phrases as well as fun sounds in the play mode. In the music mode, you will hear the heart beat, music and an endearing phrase. The light-up nose will flash with the sound.







MELODY LIST:

- 1. The Bear Went Over the Mountain
- 2. Teddy Bears' Picnic
- 3. Alouette
- 4. London Bridge
- 5. Twinkle, Twinkle, Little Star
- 6. Bicycle Built for Two

SUNG SONG LYRICS

SUNG SONG 1

Hello Doctor, I'm Teddy bear.

I'm glad you're here it shows you care.

Check my heart,

Check my ears,

And make sure I'm growing big and strong!

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat source.
- Remove the batteries when the unit is not in use for an extended period of time.
- 4. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

- 1. Please turn the unit **OFF**.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **ON**. The unit should now be ready to play again.
- If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

